


RING ORDER
1-5-3-6-2-4



Connection from dizzy to negative side of coil for points ignition system

EIGHT CYLINDER DISTRIBUTOR
CLOCKWISE ROTATION FOR
318 AND 340 CUBIC INCH
ENGINES
FIRING ORDER

SPARK PLUGS
RIGHT BANK

SPARK PLUGS

TIL 110CY/T
128 14DBL RES